



Follow these steps:

1. solder all  lines (switch turned off)
2. plug in the charger for a second (activates the battery protection board)
3. set the output of dc-dc step-up module\* to 6.4 Volts (switch turned on)
4. solder the remaining  lines (switch turned off)

